

BassBoatConcepts



Mounting Instructions

Make Sure Trailer Step Bolts Are Tight On Trailer

Tools Needed

Drill, 25/64 Drill bit, Included Hex Wrench, and 9/16 Wrench

All Stainless Steel Mounting Hardware Included

1. Place base over top step and slide as far left at possible AWAY from boat.
2. Mark four drill points.
3. Drill mounting holes.
4. Choose one piece of included grip tape and adhere to base.
5. Mount base by affixing ONE screw, washer and nut per hole through the grip tape on base NEAREST BOAT. Careful to not over tighten.
6. Mount handle by affixing one screw, washer and nut per hole on handle. Careful to not over tighten.
7. Affix final TWO screws, washers, and nuts to last two holes NEAREST HANDLE. Careful to not over tighten.
8. ENJOY - WRITE A REVIEW, SOCIAL MEDIA AND GO FISH!!

THANKS FOR PURCHASING

Disclaimer - Make sure to periodically tighten all bolts as normal road driving conditions can loosen bolts.

Phone - 951.400.5650 Email - bassboatconcepts@gmail.com